



Fig. 10. GEARBOX INNER COVER AND SELECTORS

GEARBOX INNER COVER AND SELECTORS

1	T4327	Inner cover	1	
2	T1614	Layshaft bearing	1	
3	T45	Kickstart stop	1	
4	T412	Bush (F/C spindle)	1	
5	T4288	Leaf spring	1	
6	T4289	Support plate	1	
7	T4290	Top plate	1	
8	T4291	Tab washer	1	
9	F4771	Screw	2	
10	T1606	Layshaft, needle roller bearing	1	
11	T1607	Thrust washer	2	
12	T912	Peg L/S thrust washer	1	(Also in crankcase group)
13	T989	Dowel, inner to outer cover	2	
14	T397	Quadrant	1	
15	T1896	Quadrant spindle	1	
16	—	Split pin ($\frac{5}{64}$ in. x $1\frac{3}{8}$ in.)	1	Reference only
17	14-7101	Socket screw	1	
18	14-6121	Bolt, inner cover to crankcase	1	
19	E3446	Washer, inner cover to crankcase	2	
20	14-6614	Screw, inner cover to crankcase	2	
21	14-1431	Stud, gearbox cover	2	
22	T4055	Camplate	1	
23	T4308	Selector fork mainshaft	1	
24	T4307	Selector fork layshaft	1	
25	T2166	Filler cap	1	
26	E8782	"O" ring	1	
27	E11447	Gasket, inner cover to crankcase	1	