



Fig. 13. GEARBOX OUTER COVER

Ref. No.	Part No.	DESCRIPTION	QUANTITY	REMARKS
GEARBOX OUTER COVER				
1	57-3760	GEARBOX OUTER COVER	1	
2	57-0023	Kickstarter spindle bush	1	
3	57-0057	Gearchange spindle bush	1	
4	57-0047	Kickstarter spring anchor pin	1	
5	21-0547	Guide plate stud	4	
6	57-1956	Oil seal	1	
7	57-1955	Oil seal housing	1	
8	57-4910	Gearchange quadrant	1	
9	60-3530	Rubber "O" ring	1	
10	57-0404	Quadrant return spring	2	
11	57-0406	Gearchange quadrant plunger	2	
12	57-0405	Plunger spring	2	
13	57-0407	Guide plate	1	
14	70-1612	Serrated washer	4	
15	14-0301	Nut	4	
16	57-4117	Kickstarter quadrant	1	
17	57-0031	Kickstarter return spring	1	
18	57-0024	Kickstarter axle	1	
19	57-4587	CLUTCH LEVER ASSEMBLY	1	
20	57-4588	Clutch lever	1	
21	57-1710	Lever shaft	1	
22	60-2368	Ball, $\frac{3}{8}$ in. diam.	3	
23	57-4589	Thrust plate	1	
24	57-1712	Return spring	1	
25	57-3673	Plain washer	1	
26	—	Split pin ($\frac{5}{64}$ in. x $\frac{1}{2}$ in.)		Reference only
27	21-1879	Countersunk screw	2	
28	57-1646	Rubber cover	1	
29	57-3762	Abutment for clutch cable	1	
30	60-4247	Plain washer	2	
31	14-0302	Nut	1	
32	21-2162	Screw	2	
33	14-6609	Screw	2	
34	14-6608	Screw	1	
35	57-3757	Gearchange pedal	1	
36	14-0200	Bolt	1	
37	57-2450	Pedal rubber	1	
38	57-3630	FOLDING KICKSTARTER	1	
39	57-2173	Kickstarter lever	1	
40	57-1270	Kickstarter pedal	1	
41	57-1167	Pedal locating spring	1	
42	60-2364	Steel ball, $\frac{1}{4}$ in. diam.	1	
43	21-0543	Pedal bolt	1	
44	57-2330	Pedal rubber	1	
45	57-4352	Cotter pin c/w nut and washer	1	
46	21-0544	Domed nut	1	
47	57-2160	Filler plug	1	
48	70-8782	O-ring	1	