



Fig. 9. GEARBOX INNER COVER AND SELECTORS

**GEARBOX INNER COVER AND SELECTORS**

|    |         |   |   |                           |
|----|---------|---|---|---------------------------|
| 1  | T4112   | INNER COVER   | 1 |                           |
| 2  | T1614   | Layshaft bearing  | 1 |                           |
| 3  | T45     | Kickstart stop  | 1 |                           |
| 4  | T412    | Bush (F/C spindle)  | 1 |                           |
| 5  | T1606   | Layshaft, needle roller bearing                           | 1 |                           |
| 6  | T1607   | Thrust washer   | 2 |                           |
| 7  | T912    | Peg, L/S thrust washer                                    | 1 | (Also in crankcase group) |
| 8  | T989    | Dowel, inner to outer cover                               | 2 |                           |
| 9  | T397    | Quadrant  | 1 |                           |
| 10 | T1896   | Quadrant spindle  | 1 |                           |
| 11 | —       | Split pin ( $\frac{5}{64}$ in. x $1\frac{3}{8}$ in.)      |   | Reference only            |
| 12 | 14-7101 | Socket screw ( $3\frac{1}{4}$ in. U.H.)                   | 1 |                           |
| 13 | 14-6121 | Bolt, inner cover to crankcase ( $2\frac{1}{4}$ in. U.H.) | 1 |                           |
| 14 | E3446   | Washer, inner cover to crankcase                          | 2 |                           |
| 15 | 14-6614 | Screw inner cover to crankcase ( $2\frac{1}{2}$ in. U.H.) | 2 |                           |
| 16 | 14-1431 | Stud, gearbox cover                                       | 2 |                           |
| 17 | T4055   | Camplate  | 1 |                           |
| 18 | NT261   | Camplate roller   | 2 |                           |
| 19 | T3660   | Plunger   | 1 |                           |
| 20 | T4059   | Plunger spring  | 1 |                           |
| 21 | T2172   | Plunger sleeve nut  | 1 |                           |
| 22 | T3978   | Washer  | 1 |                           |
| 23 | T2596   | Selector fork mainshaft                                   | 1 |                           |
| 24 | T913    | Selector fork layshaft                                    | 1 |                           |
| 25 | T2166   | Filler cap  | 1 |                           |
| 26 | E8782   | "O" ring  | 1 |                           |
| 27 | E11447  | Gasket, inner cover to crankcase                          | 1 |                           |